

aCapella SlatWorks

Direct Mount (SWC) - Ceiling Installation

APPLICATION:

Installing SlatWorks panels directly to a drywall ceiling.

TOOLS NEEDED:

Utility Knife, Straight Edge, Drill, #6 x 1 5/8" sharp point drywall screws (by others)

INSTALLATION INSTRUCTIONS:

1. Lay-out placement of panels on the ceiling.
2. Align panel with location lines/dimensions. Be careful to support entire panel until fully fastened to the ceiling.
3. Install panel direct to drywall ceiling using #6 x 1 5/8" black drywall screws through the Backing of the aCapella SlatWorks panel into appropriate structure. Locate screws 9" on-center across width of panel. Attach screws between raised SlatWorks panels. Be careful to support SlatWorks panel until fully fastened to ceiling.

Note: If unable to fasten to appropriate structure, use a hollow wall/ceiling anchor or pre-install 2" wide furring strips to ceiling at 24" on center.

Note: For base layers other than black, paint screw heads to match. (color match paint by others)

4. Cut and fit perimeter pieces using a utility knife and straight edge as required.

Note: Due to inconsistencies in the aCapella core thickness, some shimming may be required to align the panels edges.

HANDLING AND STORAGE

aCapella panels must be stored indoor in a dry, climate controlled environment at all times. Exposure to moisture, excessive heat or humidity can cause panels to warp and/or stain.

Panels should be stored in a flat, fully supported, horizontal position and NOT on edge. It is recommended that 2 people carry each panel. Panel should be carried on edge, being careful not to bend panel at any time. Clean white gloves are also recommended when handling aCapella panels.

