

# aCapella FLOAT - Cloud CableLock Plates - Ceiling Installation


## APPLICATION:

For ceiling mounting aCapella Float Cloud with CableLock Plates.

## TOOLS NEEDED:

Phillips Screwdriver


## MOUNTING HARDWARE:



CableLock Plate



#8 x 1/2" Screw




10' Cable

## INSTALLATION INSTRUCTIONS:


1. Lay Float panel face down on a flat, clean surface.  
**Note: Back side of each Float panel should be clearly labeled. Follow the directional label on the back of the panel for installation orientation. All panels should be installed with the same orientation.**
2. Measure 9" in from each edge of panel and mark Float Cloud. If panel is greater than 4' long, see drawings on page 2.
3. Center CableLock Plate on mark and install using #8 x 1/2" screws, three per CableLock Plate. Tighten each screw until snug. **Do not overtighten.** Repeat for all.
4. Once CableLock Plate is secured, push 1" of cable into the top of the CableLock Plate. The cable will automatically lock in place. To release cable, press down on the top of the CableLock holder and pull on the cable.

**When all CableLock Plates and cables are installed, the Float Cloud is ready to hang. Use appropriate fasteners and hardware to install the clouds from the structure. Remove all stickers before hanging.**

## MOUNTING DETAILS





#8 x 1/2" Screws



CableLock Plate

Cable



# aCapella **FLOAT - Cloud** CableLock Plates - Ceiling Installation

