

CLEANING INSTRUCTIONS

Polyester Fabric

Polyester panel fabrics are colorfast to both water-based and solvent-based cleaning solutions and may be cleaned with all conventional upholstery cleaning systems.

Note that the following are general recommendations for panel fabric only. Some fabric cleaning methods may cause damage to underlying materials in panel or wall panel systems. Contact the panel manufacturer for recommendations and precautions prior to attempting any of the following procedures.

- Vacuum the fabric periodically to remove accumulated dirt and dust. The frequency of this and any other routine maintenance is determined by end use conditions.
- Blot fresh spills immediately.
- Gently use compressed air to lightly blow off any debris.
- Gently use clean tape to blot off debris.
- Ensure that the fabric is adequately rinsed after cleaning as residual cleaning agents may accelerate soiling.
- Have the fabric professionally cleaned whenever large stains or an overall soiled condition occurs
- Resolve carpet cleaner can be used as a cleaning option.

For most water-based stains, a clean, absorbent cloth dampened with a detergent solution (e.g. 1-teaspoon laundry detergent / 1-pint warm water) should be applied to the stain. Blot the fabric with the treated cloth, working from the outer edge of the stained area moving inward. In order to effectively draw out the stain, renew the cleaning cloth frequently. Rinse well with clear water, and dry the fabric as quickly as practical. Oil-based stains may be treated in a similar manner, substituting a volatile solvent-based cleaner for the detergent solution. Always follow the manufacturer's recommendations for using such products, and always pretest an inconspicuous area of the fabric for colorfastness to the cleaning agent.

PVC and Nylon

PVC and Nylon may be cleaned with a low concentration of a mild soap in water. The solution should be applied with a sponge or soft cloth with a gentle rubbing action. Cleaners with abrasives such as scouring powders or steel wool should be avoided. Also, cleaners that contain keytones, kerosene or petroleum products must not be used.

If a PVC or Nylon encapsulated product should become ripped or torn, it can easily be repaired with a matching PVC or Nylon tape. If PVC or Nylon is not available, then a clear packing tape will work very well. As with all tapes, it is extremely important that the surface be clean and dry. When applying the tape, a sufficient amount of pressure must be used to ensure proper adhesion.

Vinyl

General Conditions: Day-to-Day Soil

Ordinary dirt and smudges can be removed with a mild soap, warm water and if necessary, a soft bristle brush to remove dirt from the crevices of deeply textured patterns. Clean from bottom of wall upward. Rinse thoroughly with clean water from the top down using a sponge. Deeply embossed wallcoverings need extra attention in case suds or loosened dirt lodge in depressed surfaces. Dry wallcovering with a soft, lint-free cloth or towel. For more difficult stains that are only surface deep, the use of a stronger detergent is recommended.

Not recommended for cleaning are steel wool or powdered abrasive cleaners because they mar the surface leaving an unsightly appearance. Unlike wallcovering with conventional finishes, active solvent type cleaning preparations such as nail polish remover, tar and bug removers, etc., can be used with PreFixx protected wallcoverings to remove residual stains that remain after cleaning with standard cleaning agents.

CLEANING INSTRUCTIONS CONT.

Co-Polymer

Be careful to avoid getting cleaning solution on the fiberglass core. It is best to apply all cleaners to the cloth or chamois and not directly on the perforated co-polymer surface.

To clean co-polymer, dust it with a soft, damp cloth or chamois and wipe the surface gently. Use soap and lukewarm water to remove light dirt. After washing and rinsing, be sure to dry the surface by blotting with a damp cloth or chamois.

Painted Panels

G&S Acoustics' Painted Panels should be cleaned using the following methods:

- Gently use compressed air to lightly blow off any debris.
- Gently use a dry cloth or soft bristle brush, such as a feather duster, to wipe away debris.

aCapella Polyester Panels

- Light dusting on regular basis to prevent buildup. A vacuum may be used
- Dirt and stains should be addressed in following manner:
- Bleach Cleanable using a 10:1 ratio mixture, standard colors only. Woodwinds finish is not bleach cleanable.

For most water-based stains, a clean, absorbent cloth dampened with a detergent solution (e.g. 1-teaspoon laundry detergent / 1-pint warm water) should be applied to the stain. Blot the panel with the treated cloth, working from the outer edge of the stained area moving inward. In order to effectively draw out the stain, renew the cleaning cloth frequently. Rinse well with clear water and dry the panel as quickly as practical. Oil-based stains may be treated in a similar manner, substituting a volatile solvent-based cleaner for the detergent solution. Always follow the manufacturer's recommendations for using such products, and always pretest an inconspicuous area of the panel for colorfastness to the cleaning agent.

Melody Polyester Panels

- Light dusting on regular basis to prevent buildup. A vacuum may be used
- Dirt and stains should be addressed in following manner:
- Bleach Cleanable using a 10:1 ratio mixture. (Unprinted and Non-Fabric covered only)
- MelodyRap fabric covered panels, refer to Polyester Fabric guide on page 1

For most water-based stains, a clean, absorbent cloth dampened with a detergent solution (e.g. 1-teaspoon laundry detergent / 1-pint warm water) should be applied to the stain. Blot the panel with the treated cloth, working from the outer edge of the stained area moving inward. In order to effectively draw out the stain, renew the cleaning cloth frequently. Rinse well with clear water and dry the panel as quickly as practical. Oil-based stains may be treated in a similar manner, substituting a volatile solvent-based cleaner for the detergent solution. Always follow the manufacturer's recommendations for using such products, and always pretest an inconspicuous area of the panel for colorfastness to the cleaning agent.